

# Battery Charging System Wiring Diagram PDF — Complete Generator Starting Battery Connection Guide

[Free Download - Generator Resource Center](#)

---

The battery charging system is a critical but often overlooked subsystem in diesel generator sets. Its primary function is to maintain the engine starting batteries at full charge so that the generator can reliably start on demand, whether for an automatic mains failure event or for scheduled testin...

**Shandong Huaquan Power Co., Ltd.**

Website: [www.huaquanpower.com](http://www.huaquanpower.com)

Email: [huaquan@huaquanpower.com](mailto:huaquan@huaquanpower.com)

Phone/WhatsApp: +86 15905360672

# Battery Charging System Wiring Diagram PDF — Complete Generator Starting Battery Connection Guide

## Introduction

The battery charging system is a critical but often overlooked subsystem in diesel generator sets. Its primary function is to maintain the engine starting batteries at full charge so that the generator can reliably start on demand, whether for an automatic mains failure event or for scheduled testing. A poorly designed or incorrectly wired battery charging system is one of the most common causes of generator startup failures in the field. The system typically comprises the engine-mounted alternator (not to be confused with the main generator alternator), a battery charger, the starting batteries, interconnecting cables, and associated monitoring and protection devices.

This comprehensive guide covers the complete wiring details for generator battery charging systems, from the engine alternator and its voltage regulator to the auxiliary battery charger, battery disconnect switches, battery monitoring devices, and the DC distribution to the generator controller and starter motor. We provide detailed pin assignments for common charging system components, wiring diagrams for both 12 V and 24 V systems, and technical specifications for cables, fuses, and chargers. The guide is suitable for generator service technicians, installation contractors, electrical engineers, and facility managers responsible for generator reliability.

A well-designed battery charging system ensures that the batteries are maintained at their optimal float voltage (typically 13.5–13.8 V for 12 V systems, 27.0–27.6 V for 24 V systems), with temperature compensation to prevent overcharging or undercharging in extreme climates. The system must also alert the operator if a charging fault occurs, as a battery failing to charge is a precursor to a failed start attempt. Modern smart battery chargers incorporate microprocessor control, multi-stage charging profiles, temperature compensation, and remote alarm outputs that integrate directly with the generator controller.

## Battery Charging System Wiring Connection Details

### Engine Alternator Charging Circuit

The engine-mounted alternator (typically 28 V or 14 V, 50–150 A) charges the starting batteries while the engine is running. It is driven by the engine's crankshaft via a V-belt or poly-V belt.

Component	Terminal	Connection	Wire Size	Notes
Alternator B+	Main output	Battery positive (via charge fuse/breaker)	16–50 mm <sup>2</sup>	Highest current path
Alternator B-	Ground	Engine ground stud	16–50 mm <sup>2</sup>	Short, direct path
Alternator D+ (WL)	Charge indicator	Controller charger excitation output (pin 11)	1.5–2.5 mm <sup>2</sup>	12/24 V, 2 A max
Alternator W (tach)	Speed signal	Controller MPU input (optional)	1.0 mm <sup>2</sup>	AC signal for RPM
Alternator S (sense)	Battery voltage sense	Battery positive terminal	1.0 mm <sup>2</sup>	Voltage sense reference
Alternator L (lamp)	Warning lamp	Dashboard indicator lamp	1.0 mm <sup>2</sup>	Optional local indicator

**Important:** The B+ cable from the alternator to the battery must be fused within 300 mm of the battery positive terminal. The fuse rating should be 125–150% of the alternator's rated output current.

### Battery Charger Circuit (Mains-Powered)

The auxiliary battery charger maintains the batteries when the generator is not running, powered from the mains supply or from the generator output during operation.

Battery Charger Terminal	Function	Connection	Wire Size	Notes
AC Input (L)	Live	From mains via dedicated breaker	2.5 mm <sup>2</sup>	MCB rated 6–16 A
AC Input (N)	Neutral	Neutral busbar	2.5 mm <sup>2</sup>	
AC Input (E)	Ground	Ground busbar	2.5 mm <sup>2</sup>	
DC Output (+)	Positive	Battery positive terminal	6–16 mm <sup>2</sup>	Via 1.25x rated fuse
DC Output (-)	Negative	Battery negative terminal	6–16 mm <sup>2</sup>	Direct connection
Remote Sense (+)	Voltage sense	Battery positive terminal	1.0 mm <sup>2</sup>	For voltage drop compensation
Remote Sense (-)	Voltage sense	Battery negative terminal	1.0 mm <sup>2</sup>	For voltage drop compensation
Alarm Relay (NO/COM)	Fault output	Controller alarm input	1.0 mm <sup>2</sup>	Dry contact, 250 VAC/2 A
Battery Temp Sensor	Temperature probe	Battery top (central cell)	1.0 mm <sup>2</sup>	Temperature compensation

### Starting Circuit Wiring

The starting circuit delivers high current (hundreds of amps for a few seconds) from the batteries to the starter motor.

Component	Terminal	Connection	Wire Size	Notes
Battery +	Positive terminal	Starter solenoid B+	35–120 mm <sup>2</sup>	As short as possible
Battery -	Negative terminal	Starter motor ground terminal	35–120 mm <sup>2</sup>	Or engine block ground
Battery -	Negative terminal	Generator frame ground	35–120 mm <sup>2</sup>	For controller/chassis
Starter Solenoid S	Control signal	Starter relay output (controller)	2.5–4 mm <sup>2</sup>	12/24 V from controller
Starter Solenoid B+	Battery input	Battery positive via cable	35–120 mm <sup>2</sup>	High current stud
Starter Motor M	Motor terminal	From solenoid output	35–120 mm <sup>2</sup>	Engage contact

## Battery Charging System Pin Assignments

### Typical Generator Controller Battery Monitoring Interface

Controller Pin	Function	Signal Type	Normal Range	Alarm Condition
DC Supply +	Supply input	8–35 VDC	12 V or 24 V nominal	Below 10 V (12V) / 20 V (24V)
DC Supply -	Supply ground	0 VDC	—	—
Charger Failure Input	Charger status	Digital NC to ground	Closed (charging OK)	Open (charger fault)
Battery Voltage (Ain)	Battery volts	0–35 VDC analogue	12.0–14.5 V (12V)	Below 11.5 V / Above 15 V

| Battery Temp (Rin) | Battery temperature | PT100/NTC | 20–30°C | Below -20°C / above 60°C |  
 | Charger Excitation Out | D+ signal | 12/24 VDC output | Active when engine running | Inactive = alternator not charging |

**Smart Battery Charger Connection Reference**

Charger Model	Voltage	Charging Current	Charging Profile	Remote Alarm	Temp. Comp.
Victron Energy Blue Power	12/24 V	10–50 A	4-stage (bulk, abs, float, storage)	Yes (potential free)	Yes (internal)
Mastervolt Battery Charger	12/24 V	10–100 A	3-stage + temperature	Yes (NO/NC)	Yes (external probe)
Mean Well PB-600	12/24 V	10–40 A	3-stage	Yes (relay output)	Yes (optional)
Schumacher SC1308	12 V only	8–30 A	3-stage (bulk/abs/float)	Yes (LED + alarm relay)	No
NOCO Genius GEN5	12/24 V	5–20 A	7-stage (smart)	Yes (RPM sense)	Yes
CTEK MXS 25	12/24 V	25 A	8-stage	Yes (status output)	Yes (temp sensor)
SmartGen BCM-4010	12/24 V	10–40 A	3-stage + genset interface	Yes (Modbus RS485)	Yes
Lester Electrical Summit	12/24 V	15–50 A	Multi-stage profile	Yes (CAN bus)	Yes

**Battery Charging System Connection Specifications**

Parameter	12 V System	24 V System	Notes
Nominal Battery Voltage	12 VDC	24 VDC	—
Float Voltage	13.5–13.8 V	27.0–27.6 V	At 25°C
Equalize Voltage	14.4–14.8 V	28.8–29.6 V	Periodic, 1–2 hours
Absorb Voltage	14.2–14.6 V	28.4–29.2 V	Bulk charging phase
Temperature Compensation	-3 mV/°C/cell	-3 mV/°C/cell	Typical for lead-acid
Battery Capacity (typical)	100–300 Ah	100–200 Ah	Per generator size
Cold Cranking Amps (CCA)	800–1500 A	600–1200 A	Engine displacement dependent
Alternator Charging Voltage	14.0–14.5 V	28.0–29.0 V	Engine alternator output
Alternator Rating	50–120 A	50–150 A	Standard for generator engines
Battery Charger Output	10–50 A	10–40 A	Mains-powered charger
Max Voltage Drop (cables)	< 0.5 V at full load	< 0.5 V at full load	Positive + negative combined
Cable Max Length (battery to starter)	< 1.5 m	< 1.5 m	Longer = larger cable required
Ground Cable Size	>= Positive cable	>= Positive cable	Equal or larger cross-section
Battery Fuse Type	Class T or ANL	Class T or ANL	Fast-acting, high interrupt
Operating Temperature	-20°C to +50°C	-20°C to +50°C	Battery rated for environment
Recommended Battery Type	Lead-acid AGM	Lead-acid AGM	VRLA, maintenance-free
Standards Compliance	IEC 60095, SAE J537	IEC 60095, SAE J537	—

## Battery Selection and Sizing Guide

### *Battery Capacity Requirements by Generator Rating*

Generator Rating	Battery System	Recommended Ah	Recommended CCA	Number of Batteries
10–30 kVA	12 V	100–120 Ah	800–1000 CCA	1
31–75 kVA	12 V	120–150 Ah	900–1200 CCA	1
76–150 kVA	24 V	100–120 Ah (x2)	800–1000 CCA (x2)	2 (series)
151–300 kVA	24 V	120–150 Ah (x2)	900–1200 CCA (x2)	2 (series)
301–600 kVA	24 V	150–200 Ah (x2)	1200–1500 CCA (x2)	2 (series)
601–1000 kVA	24 V	200–250 Ah (x2)	1500–2000 CCA (x2)	2 (series)
1001–2000 kVA	24 V	250–300 Ah (x2)	2000–2500 CCA (x2)	2 (series, or parallel banks)

### *Cable Sizing for Battery Connections*

Cable Length (m)	Current (100 A)	Current (200 A)	Current (500 A)	Current (1000 A)
0.5 m	16 mm <sup>2</sup>	35 mm <sup>2</sup>	70 mm <sup>2</sup>	120 mm <sup>2</sup>
1.0 m	25 mm <sup>2</sup>	50 mm <sup>2</sup>	95 mm <sup>2</sup>	150 mm <sup>2</sup>
1.5 m	35 mm <sup>2</sup>	70 mm <sup>2</sup>	120 mm <sup>2</sup>	185 mm <sup>2</sup>
2.0 m	50 mm <sup>2</sup>	95 mm <sup>2</sup>	150 mm <sup>2</sup>	240 mm <sup>2</sup>
3.0 m	70 mm <sup>2</sup>	120 mm <sup>2</sup>	185 mm <sup>2</sup>	300 mm <sup>2</sup> (paralleling)

## Download PDF — Battery Charging System Wiring Diagram

[!Download PDF\(\)](#)

Click the button above to download the complete Battery Charging System Wiring Diagram PDF. This comprehensive reference includes:

- Full battery charging system schematic for 12V and 24V generator systems
- Engine alternator wiring diagram with D+ excitation circuit
- AC mains-powered battery charger connection diagram
- Dual battery series connection for 24V systems
- Parallel battery bank wiring for high-capacity requirements
- Battery disconnect switch wiring and interlock circuits
- Battery monitoring system wiring (voltage, temperature, current)
- Battery charger alarm integration with generator controller
- Cable sizing table for all battery connection lengths
- Battery heater wiring for cold climate applications

- Ground fault detection circuit for battery systems
- Recommended fuse/breaker placement diagram

The PDF is 2.2 MB, vector graphics, A3 format, suitable for field printing and on-screen viewing. Includes commissioning checklist and maintenance schedule.

## 15 Frequently Asked Questions About Battery Charging System Wiring

### **1. Why are two 12V batteries used in series for 24V systems instead of a single 24V battery?**

Using two 12V batteries in series provides higher cranking current capacity, better physical size distribution for mounting, easier replacement (12V batteries are universally available), and improved reliability (if one battery fails, the system voltage drops but may still crank the engine in some cases). Single 24V starter batteries exist but are less common in the generator industry.

### **2. What is the correct cable size for battery-to-starter connections?**

The cable must be sized to carry the starter's full locked-rotor current (400–1500 A for typical generator engines) with less than 0.5 V total voltage drop. For a 1-meter cable run: 35 mm<sup>2</sup> for 200 A, 70 mm<sup>2</sup> for 500 A, 120 mm<sup>2</sup> for 1000 A. Always use welding-grade or SAE-rated cable with fine-strand copper conductors for flexibility and high current capacity.

### **3. How do I wire a dual battery bank for a 24V system?**

Connect Battery 1 positive to Battery 2 negative using a 35 mm<sup>2</sup> or larger jumper cable. Battery 1 negative becomes the system ground (0 V). Battery 2 positive becomes the system positive (+24 V). The battery charger output connects across the full series (positive to Battery 2 +, negative to Battery 1 –). For equal charging, use a battery balancer across the midpoint.

### **4. Why does my battery charger show AC power OK but no DC output?**

Possible causes: (a) Incoming AC voltage below the charger's minimum operating threshold, (b) Battery too deeply discharged — some chargers require a minimum voltage on the battery terminals before starting the charging cycle, (c) Blown internal fuse, (d) Battery temperature sensor detecting a fault condition if fitted, (e) Charger in protect mode from a short circuit condition on the output. Measure DC output voltage with a multimeter at the charger terminals — if 0 V with AC input present, the charger likely requires service.

### **5. What is the purpose of battery temperature compensation?**

Battery voltage requirements change with temperature. At low temperatures, the float voltage must be increased to fully charge the battery. At high temperatures, the float voltage must be reduced to prevent overcharging and gassing. Without temperature compensation, batteries in hot climates are overcharged (leading to water loss and reduced life) while batteries in cold climates are undercharged (leading to sulfation). The compensation coefficient is typically -3 mV per °C per cell for lead-acid batteries.

### **6. Can I use automotive starting batteries for generator duty?**

Automotive batteries are designed for short high-current bursts and shallow discharges. For generator duty, use heavy-duty commercial/industrial batteries designed for deep-cycle and standby applications. Recommended types: Lead-acid AGM (Absorbent Glass Mat) or gel-cell VRLA (Valve Regulated Lead Acid). These have lower self-discharge, better vibration resistance, and longer service life in standby generator applications.

### **7. How often should I replace generator starting batteries?**

Generator starting batteries should be replaced every 3–5 years for standard duty, 2–3 years for severe duty (high temperature or frequent cycling). Even if the batteries appear functional, internal resistance increases with age, reducing cranking capability. Many generator controllers can track battery age and issue a replacement reminder. Always replace both batteries in a 24V system as a pair.

### **8. What is the D+ (exciter) terminal on the engine alternator?**

The D+ terminal provides a small positive voltage to the alternator's internal voltage regulator to initiate charging. After the engine starts and the alternator begins producing, the D+ terminal is energized by the alternator's own output. Before engine start, the D+ terminal receives voltage from the generator controller's charger excitation output. This starts the alternator charging. The D+ circuit also drives the "charge fail" detection — if D+ voltage is absent while the engine is running, the controller generates a "Charger Failure" alarm.

### **9. How do I wire a battery disconnect switch?**

Install the disconnect switch on the battery positive cable between the battery positive terminal and the first load (starter solenoid). Use a continuous-duty switch rated for the maximum starting current (typically 500–1500 A intermittent, 100–200 A continuous). A solenoid-type disconnect (remote-controlled) allows the generator controller to isolate the battery automatically and prevents parasitic drain during long idle periods.

### **10. Why does my generator fail to start after being idle for 2 weeks?**

The most common cause is battery self-discharge combined with parasitic drain from the generator controller and other electronics. Even in standby mode, the generator controller draws 50–300 mA continuously. Over two weeks, this can discharge batteries below the minimum voltage required for starting. Solutions: (a) Ensure the battery charger is operational and mains supply is available, (b) Check that the battery disconnect switch is closed, (c) Test battery health (specific gravity or conductance), (d) Verify battery charger output voltage is 13.5–13.8 V (12V system) or 27.0–27.6 V (24V system).

### **11. What protection devices should be installed in the battery circuit?**

Essential protection: (a) Battery fuse (Class T or ANL type) within 300 mm of battery positive terminal, rated at 150% of expected maximum current, (b) Battery disconnect switch for maintenance isolation, (c) Reverse polarity protection diode on controller supply line (most controllers have this internally), (d) Over-current protection on the battery charger AC input (MCB), (e) Over-current protection on the battery charger DC output (fuse or breaker).

### **12. Can I use a single battery charger for two battery banks?**

A single charger with enough output current rating can charge two battery banks if they are connected in parallel (both positives together, both negatives together) and are the same age, type, and capacity. For truly independent banks (e.g., engine start bank + control panel bank), use a dual-output battery charger or individual chargers for each bank. Some smart chargers have dual output channels that can maintain separate banks independently.

### **13. What is the correct way to measure battery voltage for controller monitoring?**

Connect the battery voltage monitoring input directly to the battery terminals (not through the circuit breaker or disconnect switch) using 1.0 mm<sup>2</sup> wire. This ensures the controller reads true battery voltage without the voltage drop across protection devices. Place a 1 A fuse in the positive sense wire near the battery terminal for protection.

### **14. How do I ground the battery negative terminal?**

Connect the battery negative terminal to the engine block with a short (under 600 mm) cable of the same gauge as the positive cable, or one size larger. From the engine block, connect to the generator frame ground busbar. The ground path must be capable of carrying the full starting current. Do not rely on the chassis or frame through

paint or rust-prone joints — use dedicated ground cables with proper ring terminals and star washers.

### **15. Why does the battery charger alarm frequently trigger?**

Common causes: (a) AC input voltage fluctuating outside the charger's input range, (b) Battery sulfated or damaged and unable to accept charge, (c) Charger output fuse blown or loose connection, (d) Battery temperature sensor not attached or faulty, (e) Charger is undersized for the battery bank — trying to charge large batteries with a small charger triggers thermal protection, (f) Ambient temperature at the charger exceeds its rating. Check the charger manufacturer's specifications for alarm conditions.

## **Advanced Battery System Wiring Configurations**

### **Battery Bank Wiring Topologies**

Series Configuration (for 24V Systems):

Two 12V batteries connected in series produce 24V. This is the standard configuration for most generator sets above 75 kVA.

- Battery 1 Negative → System Ground
- Battery 1 Positive → Battery 2 Negative (series jumper cable, 35mm<sup>2</sup> minimum)
- Battery 2 Positive → Starter Solenoid +24V
- Battery Charger + → Battery 2 Positive
- Battery Charger – → Battery 1 Negative
- Controller DC+ → via 5A fuse from Battery 2 Positive
- Controller DC– → Battery 1 Negative

■■ Important: For equal charging, install a 12V battery balancer (equalizer) across the series connection midpoint. Without a balancer, one battery may become overcharged while the other remains undercharged, significantly reducing battery life.

Parallel Configuration (for Increased Capacity):

Two or more identical batteries connected in parallel increase the total Ah capacity while maintaining the same voltage.

- All Battery Positives connected together → system positive
- All Battery Negatives connected together → system ground
- Use equal-length cables from each battery to the common positive and negative busbars
- Total capacity = sum of individual battery Ah ratings

■■ Parallel Battery Warning: Batteries in parallel must be identical (same brand, model, age, capacity, and manufacturing date). Never parallel old and new batteries. For generator applications, series for 24V is strongly preferred over parallel 12V.

### **Battery Monitoring System Wiring**

A battery monitoring system (BMS for batteries, distinct from generator BMS) provides real-time data on battery health and helps predict failures before they occur.

Monitoring Parameter	Sensor Type	Controller Connection	Alarm Thresholds
Voltage (total)	Direct measurement	Controller DC supply input	<11.5V (12V) / <23V (24V)
Voltage (each battery)	Individual monitoring	Analogue inputs	>0.3V difference between batteries
Current (charge/discharge)	Hall effect DC current sensor	Controller analogue input	Charge >20A = bulk charging
Temperature	PT100 or NTC probe on battery terminal	Controller resistance input	>50°C = overheat alarm
Internal Resistance	Conductance tester or inline module	RS485 / Modbus	>1.5x baseline = replacement due
Electrolyte Level	Float switch in each cell	Digital input	Float opens = low level
Specific Gravity (for flooded)	Hydrometer with sensor	Modbus	<1.200 = discharged

Monitoring System Wiring:

1. Install a DC Hall-effect current sensor around the main battery positive cable (between battery and starter solenoid)
2. Connect sensor output (0–5V or 4–20mA) to the generator controller's analogue input
3. Install battery temperature probes on the positive terminal of each battery (use thermal conductive paste)
4. Connect temperature probes to the controller's resistance inputs (PT100 or NTC as supported)
5. For individual battery voltage monitoring, use voltage divider circuits (precision 0.1% resistors) connected to separate analogue inputs. Ensure the divider output does not exceed the controller's input voltage range.

**Battery Charger Selection and Sizing**

The battery charger must be correctly sized for the generator's battery bank to ensure reliable charging without overcharging or undercharging.

Charger Current Rating Formula:

- Recommended charger output current = 10–25% of battery bank capacity (C20 rating)
- For a 200 Ah battery bank: recommended charger = 20–50 A
- For a 100 Ah battery bank: recommended charger = 10–25 A
- Multiple batteries do not sum for charging current — use the total bank capacity for calculation

Charger Selection Considerations:

Factor	Recommendation
Charging Profile	3-stage or multi-stage (Bulk, Absorption, Float)
Temperature Compensation	Mandatory for generator applications
Remote Alarm Output	Required for integration with generator controller
Input Voltage Range	Wide input (85–265 VAC) for voltage fluctuations
Efficiency	>85% recommended to minimize heat generation
Enclosure Rating	IP20 minimum for panel mount, IP65 for outdoor
Battery Type Support	Selectable for Flooded, AGM, Gel, or Lithium
Communication	RS485 Modbus for remote monitoring (advanced)

## ***Battery Disconnect and Protection Wiring***

1. **Main Battery Disconnect Switch:** Install a continuous-duty battery disconnect switch on the positive battery cable between the battery and the starter solenoid. Rating: 500–1500 A intermittent, 100–200 A continuous. For remote control, use a solenoid-operated disconnect (12/24V coil) that can be controlled by the generator controller.
2. **Battery Fuse:** Install a Class T or ANL fuse within 300 mm of the battery positive terminal. Rating: 150% of the maximum expected current (starter current for starting circuit, charger current for charging circuit). For a 1000A starting circuit, use a 500–600A Class T fuse (fast blow, 200 kA interrupt rating).
3. **Starter Solenoid Isolation:** The starter solenoid primary circuit should be isolated from the controller start output using an intermediate relay. The controller start output (typically 10A rated) energizes the relay coil, and the relay contacts (rated for the solenoid current) complete the starter circuit. This protects the controller from the solenoid's inductive kickback.

Battery Disconnect Sequence for Maintenance:

1. Stop generator manually or allow automatic shutdown to complete
2. Turn generator controller to OFF position
3. Open battery disconnect switch
4. Open battery charger AC supply breaker
5. Wait 60 seconds for controller capacitors to discharge
6. Verify zero voltage at controller DC terminals with multimeter before servicing

## ***Cold Climate Battery System Modifications***

For generator installations in cold climates (ambient below -20°C), additional battery system modifications are required:

1. **Battery Heater Pad:** Install a 25–50 W silicone heater pad beneath each battery. Connect to a thermostatic controller that energizes the heater when battery temperature drops below 5°C. Wire the heater through a 10 A fused circuit from the battery charger AC supply.
2. **Battery Box Insulation:** Use an insulated battery box (50 mm closed-cell foam) to retain engine heat and heater pad warmth. Include ventilation for hydrogen gas release (minimum 100 cm<sup>2</sup> vent area at the top).
3. **Increased Charger Voltage Setpoint:** Use a 24.5 V or 25 V battery charger output for -20°C operation (with temperature compensation). Some smart chargers automatically adjust the voltage based on ambient temperature.
4. **Higher CCA Batteries:** Select batteries with CCA rating 1.5x the standard requirement for the engine. At -20°C, battery cranking capacity drops to approximately 50% of the 25°C rating.

## **Related Downloads**

- [\[Generator Control Panel Wiring Diagram\]\(\)](#) — Full generator control system connections
- [\[Automatic Voltage Regulator Wiring PDF\]\(\)](#) — AVR connection and adjustment guide
- [\[Fuel Pump Wiring Diagram PDF\]\(\)](#) — Diesel generator fuel system wiring

- [ATS Wiring Diagram PDF]() — Automatic transfer switch wiring schematics
- [Generator Maintenance Checklist PDF]() — Pre-commissioning verification document

---

This Battery Charging System Wiring guide is provided by HuaQuan Power — professional generator set manufacturer. For battery system design, charger selection, or technical support, contact our electrical engineering team.

© HuaQuan Power. All rights reserved. Wiring diagrams and specifications are for reference. Always follow local electrical codes and battery/charger manufacturer instructions for final installation.

---

**Shandong Huaquan Power Co., Ltd.**

Contact: +86 15905360672 | [huaquan@huaquanpower.com](mailto:huaquan@huaquanpower.com)

Website: [www.huaquanpower.com](http://www.huaquanpower.com)